



Plissee line

P l i s s e e l i n e



Šňurové ovládání			Ovládání kulíčkovým řetízem			Ovládání elektrickým pohonem			Ovládání úchytem			Pevné provedení
P1100  Str. 12	P1102  Str. 12	P1105  Str. 12	P1200  Str. 21	P1202  Str. 21	P1205  Str. 21	P1300  Str. 28	P1302  Str. 28	P1305  Str. 28	P1400  Str. 35	P1402  Str. 35		P1000  Str. 49
P1110  Str. 13	P1112  Str. 13	P1115  Str. 13	P1210  Str. 22	P1212  Str. 22	P1215  Str. 22	P1310  Str. 29	P1312  Str. 29	P1315  Str. 29	P1410  Str. 36	P1412  Str. 36	P1415  Str. 36	P1034  Str. 49
P1120  Str. 14	P1122  Str. 14	P1125  Str. 14	P1220  Str. 23	P1222  Str. 23	P1225  Str. 23	P1320  Str. 30	P1322  Str. 30	P1325  Str. 30	P1420  Str. 37	P1422  Str. 37	P1426  Str. 38	P1035  Str. 49
P1130  Str. 15	P1131  Str. 16		P1230  Str. 24	P1231  Str. 25		P1330  Str. 31	P1331  Str. 32		P1434  Str. 39	P1435  Str. 40		P1040  Str. 49
P1140  Str. 17	P1141  Str. 18			P1241  Str. 26		P1340  Str. 33	P1341  Str. 34		P1436  Str. 41	P1437  Str. 42		P1042  Str. 49
P1150  Str. 19									P1450  Str. 43	P1452  Str. 43		P1080  Str. 48
									P1460  Str. 44	P1461  Str. 45		P1081  Str. 48
									P1462  Str. 46	P1463  Str. 47		P1085  Str. 48

